



Place cot side bracket over rail as shown in the image.

Line up the chained pin with both of the holes.



Push pin through both holes, make sure it is secure.



Finished item.

